

## **DISPOSABLE INHALABLE SAMPLER (DIS)**

MCE's will have a BLUE dot on the bag PTFE will have a YELLOW dot on the bag PVC will have an ORANGE dot on the bag.

1) Lift one side of your DIS cap at a time for removal.



Warning: Twisting the cap will cause the DIS to come apart and potentially impact the DIS integrity.

2) The cap of the DIS will clip into place on the bottom of the DIS for storage during sampling.



GALSON LABORATORIES INC. IS NOW PART OF SGS, THE WORLD'S LEADING INSPECTION, VERIFICATION, TESTING AND CERTIFICATION COMPANY.

3) Remove the air flow cap from the stem of the DIS.



4) Connect the DIS to the pump via the provided tubing and turn the pump on to begin event.



5) When finished, remove the DIS from tubing and re-seal both openings.





6) Place the DIS back in original bag for shipment back to SGS Galson.



Questions? Contact SGS Galson 24/7/365 at 1-888-432-5227, or utilize our large sampling video instructional selection at www.SGSGalson.com.