



SAMPLING WITH IOMs.

MCE's will have a **BLUE** dot on the bag
PTFE will have a **YELLOW** dot on the bag
PVC will have an **ORANGE** dot on the bag.

- 1) Lift one side of your IOM cap at a time for removal.



Warning: Twisting the cap will cause the IOM to come apart and potentially impact the IOM integrity.

- 2) Remove the air flow cap from the stem of the IOM.



GALSON LABORATORIES INC. IS NOW PART OF SGS, THE WORLD'S LEADING INSPECTION, VERIFICATION, TESTING AND CERTIFICATION COMPANY.

- 3) Connect the IOM to the pump via the provided sampling tubing and turn on the pump to begin event.



Note: Pump type may vary depending on inventory availability.

- 4) When finished, remove IOM from tubing and place both caps back on IOM



- 5) Place IOM back in original bag for shipment back to SGS Galson.



Questions? Contact SGS Galson 24/7/365 at 1-888-432-5227.