



PPI Sampling Quick Start Guide



Color will vary depending on model.

BEFORE SAMPLING

- 1) Remove PPI from heat sealed bag when ready to sample. Save the bag for later use with same sampler.



- 2) Remove the black cap. Connect PPI to pump tubing after allowing the pump to warm up for 1.5 minutes. You are now sampling.



GALSON LABORATORIES INC. IS NOW PART OF SGS, THE WORLD'S LEADING INSPECTION, VERIFICATION, TESTING AND CERTIFICATION COMPANY.

AFTER SAMPLING

- 1) Disconnect the sampler from pump tubing and replace the black cap back on the outlet of the PPI. Place the provided sticker over the inlet of the PPI to seal the sample.



- 2) Place back in original sample bag and ship back to SGS Galson.



Questions? Contact SGS Galson 247/365 at 1-888-432-5227

CALIBRATION

- 1) Attach the calibration adapter by placing it over the top of the PPI sampler.



- 2) The tubing connected to the calibration adapter connects to the calibration device. The outlet of the PPI (from which the black cover was removed) will be connected to the pump tubing. Allow the pump to warm up for at least 1.5 minutes to achieve a true flow.

TWISTING THE CALIBRATION CHAMBER MAY CAUSE YOUR SAMPLER TO OPEN, AND NEGATE YOUR SAMPLES. Simply pull up on the calibration chamber to remove.

- 3) When calibration is complete, place the calibration adapter back in its bag and ship back to SGS Galson.

CALIBRATION CHAMBERS ARE NOT DISPOSABLE AND MUST BE RETURNED TO SGS GALSON. FAILURE TO DO SO WILL RESULT IN REPLACEMENT FEES.

Questions? Contact SGS Galson 247/365 at 1-888-432-5227